はじめに

このたびは、「SoftBank 840SC」をお買い上げいただき、まことにありがとうございます。

- SoftBank 840SC をご利用の前に、「クイックスタート」、「お願いとご注意」および「取扱説明書(本書)」をご覧になり、正しくお取り扱いください。
- ご契約の内容により、ご利用になれるサービスが限定されます。
- SoftBank 840SC は、3G 方式に対応しております。

ご注意

- 本書の内容の一部でも無断転載することは禁止されております。
- ・ 本書の内容は将来、予告無しに変更することがございます。
- ・ 本書の内容については万全を期しておりますが、万一ご不審な点や記載漏れなどお気づきの点がございましたら、お問い合わせ先(◆P.15-32)までご連絡ください。
- 乱丁、落丁はお取り替えいたします。

本書の最新版は、ソフトバンクモバイルのホームページよりダウンロードできます。 http://www.softbank.jp/mb/r/support/840sc/

お買い上げ品の確認

SoftBank 840SC 本体のほかに、次の付属品がそろっていることをお確かめください。付属品は、オブション品としても取り扱いしております。

付属品、オプション品につきましては、お問い合わせ先(◆P.15-32)までご連絡ください。

電池パック [SCBAM1]



SoftBank 840SC

クイックスタート

お願いとご注意



保証書

_	£	展 田 書
74.0	18	\$100C (4759)271549
nß:	- F	SCAAX 12/3/4
k in	#O	
20 10	sen	15
N 15 M CE	211.07	70.
PK III	RI TO	製料16/0E0/51年間
271.	1973	76 4 9 0
087	204	

- •840SC の充電には、ソフトバンクが指定した充電器(オプション品)を使用してください。
- ・840SC では microSD™ / microSDHC™ メモリカードに対応しています。ご利用にあたっては、市販の microSD™ / microSDHC™ メモリカードを購入してください。
- •本書では、microSD™/microSDHC™メモリカードを「メモリカード」と記載しています。
- Samsung New PC Studio は、SAMSUNG ホームページ(http://jp.samsungmobile.com/pc/lineup/840download.html)から ダウンロードしてご利用いただけます。

			— ×=			
•••••	 				 	
	 				 	· · · · · · · · · · · · · · · · · · ·
•••••	 ••••••	• • • • • • • • • • • • • • • • • • • •		• • • • • • • • • • • • • • • • • • • •	 •••••	• • • • • • • • • • • • • • • • • • • •
••••••	 				 	· · · · · · · · · · · · · · · · · · ·
•••••	 				 	· · · · · · · · · · · · · · · · · · ·
•••••	 	•••••			 	• • • • • • • • • • • • • • • • • • • •
	 				 	······································
	 				 	· · · · · · · · · · · · · · · · · · ·

.

本書の 構成

840SC をお使いになるための準備や基礎的な知識、基本的な共通操作をまとめて説明 しています。必ずお読みください。

共通機能/共通操作

電話

準備/基礎知識

メール 4

3

840SC の代表的な機能を、章単位でまとめて説明しています。お使いになりたい機能 の章をお読みください。

インターネットテレビ6

SoftBank
SoftBank 8405C
949939->

最初に 「クイックスタート」 をお読みください。

		カメラ/静止画編集	7
		メディアプレイヤー	8
	840SC で利用できるその他の便利なツール(道具)やサービスについて説明しています。	エンタテイメント	9
	04000 C作り用できるとのIBの操作がタノール(追案)ドゲーに入について記述しているす。	ツール	10
	840SC のセキュリティを強化する機能を説明しています。	セキュリティ	11
	840SC でのデータの管理方法について説明しています。	データフォルダ/メモリ	12
	データ通信やパソコン接続、データのバックアップについて説明しています。	通信/バックアップ	13
.]	840SC を使いこなすためのカスタマイズ方法について説明しています。	カスタマイズ	14
	840SC についての資料や各種情報、索引をまとめています。	資料/付録	15
			iii

機能の探しかた

パラパラと めくって探す

本機の新しい 魅力を発見しましょう。

各誌面の内容は説明のためのサンプルです。実際の誌面とは異なります。

ページの端にはサイドインデックスが付いています。目的の章をすばやく確認することができます。



●各ページでは上の例のように、縦組み文字で章 の番号とタイトルが書かれています。本書を閉 じていても、章の区切りがわかりやすくなって います。 章の始まりには、扉ページが付いています。 区切りの目安にしましょう。



●章の冒頭などには、その章で説明する機能やサービスの内容をまとめた概要ページがあります。 ここで全体像をつかんでください(一部ない章もあります)。

説明ページのレイアウトはいくつかのパターンに分かれています。それぞれのパターンの意 味を覚えておけば、必要な箇所だけを読むことができます。

●基本操作パターン



機能やサービスの基本操作 を説明しているページです。 章や項目の前半にあります。

●応用操作パターン



機能やサービスの応用的な操作を説明しているページです。 章の後半にあります。

設定操作パターン

NEWS NAMES	
	AT USE CATURET
XEXE-1624-3510080188	(ATS 02) -CATS 0-7) - BOOKS - BASSES ET LA -BOOKS OF
WINTER CONTRACTOR OF THE PERSON OF T	HEATTHE ATTREMETERS.
MBL 4 CUESTAS	#15-02 - Cala - B.201 - GDE F + + 5 - B.201 - GDDG #15-1 - B.(00) - GDD
ACHEROMEN S	・ できることが、自動機に一切などは ・データンとのできませんと思うが、「おおおで」」、「よで」カード」を表 ・より、 ・組織、カッドに対象があるとは関係しまりませるとは関係を関する。 自動機に、アンドンを表現した。
2E30139757E68	HAY-BOX-GREEN-COL
2E3-608-71397579348860248	191.021.977 National Company of the
2E16967(1)2777839060E83	(4.5)A-PEG 8(A)-(2.8/497+7)-(7/47/97+78) ((3.57-7)(2.8(87+3.5-8.90)
メモンもの表でインテアップする場合に参与的なをする	1810-188 803/488/037-7/48802-4018 404/408
75-97-7587-19-58(418	は日本の大力・製造の一次を設定し、日本を表示・ファイルを表 日本の製作人力・製造の一次を設定し、設定を表示・ファイルを表 を記載して必要する。

本機の設定変更を説明して いるページです。カスタマ イズの章にあります。 全体像が一覧できる「目次」と、章内の内容がわかる「章目次」を活用しましょう。



●「目次」には、この取扱説明書の章構成と各章内の 見出しが記載されています。また、各章の扉ページに入っている「章目次」は、章内の内容が詳しく 記載されています。目的に応じて使い分けてくだ さい。 用語と目的機能で引ける3つの「索引」で目的の機能や用語をすばやく見つけましょう。



◆本機内の用語があいうえお順に並んでいる「用語索引」と、「登録する」「消去する」などの目的別にまとめた「目的別索引」、応用操作のある機能をまとめた「便利な機能索引」を「資料/付録」の章に掲載しています。ご活用ください。

目的の機能や 用語を探す

いろいろな方法で、 検索が行えます。

各誌面の内容は説明のためのサンプルです。実際の誌面とは異なります。

メニューなどの項目の意味や操作を調べる ときは、「機能一覧」がおすすめです。



 「資料/付録」の章の「機能一覧」は、本機のメニュー 構造に沿って、各項目の掲載ページを記載してい ます。操作中に気になる項目があれば、ここから すぐにジャンプできます。 画面に表示されるアイコンの意味を知りたいときは、「ディスプレイ」をご覧ください。




「準備/基礎知識」の章にある「ディスプレイ」では、ディスプレイに表示されるアイコンの意味を掲載しています。知らないアイコンが表示されたときは、すぐに確認しましょう。

表示やアイコン の意味を探す

気になる項目や アイコンを調べましょう。


各誌面の内容は説明のためのサンプルです。実際 の誌面とは異なります。

本書の記載パターン



各誌面の内容は説明のためのサンプルです。実際の誌面とは異なります。

設定操作パターン 各機能のカスタマイズ方法を表形式で説明しています。



応用操作パターン 各機能の応用操作を統一フォーマットで簡単に説明しています。 使いこなしチェックで記載されている機能のほかにも、さまざまな応用操作が記載されています。



表記の見かた

本書では、「SoftBank 840SC」を「本機」と表記しています。あらかじめご了承ください。

また、主にお買い上げ時の状態を基準に説明しているため、設定を 変更された場合、本機の表示や動作が本書の記載と異なることがあ ります。

ディスプレイの表記と本機のイラストについて

記載している画面は、表示されている内容や番号などが実際の画面 と異なる場合があります。操作の目安としてご利用ください。 本書のイラストはイメージイラストであり、実際の商品とは形状が

異なる場合があります。 本書では、画面を見やすくするために、待受画面の壁紙の設定を「なし」にした状態で掲載している場合があります。

確認/警告メッセージについて

操作中、本書に記載していないメッセージが表示されることがあります。確認や警告のメッセージが表示されたときは、そのメッセージをよく読んで内容をご確認ください。


ボタンの使いかたと表記について

本書では、本機のボタンをすべて記号で表記しています。「各部の名称と機能!(�P.1-3)を参照してください。

ソフトキーとマルチファンクションボタンの操作については、次のように表記しています。

ソフトキー

ディスプレイの最下段(ソフトキーエリア)には「選択」「保存」のような、操作や設定の選択肢が表示されます。これらの内容を実行するには、その表示位置に対応するソフトキーを押します。




ソフトキー操作の表記



マルチファンクションボタン

マルチファンクションボタンは、上下左右の4箇所を押せるボタンです。目的の項目を選択するときや文字入力画面でカーソルを移動するとき、画面をスクロールするときなどに使います。

マルチファンクションボタン操作の表記




- □ または 回 を押すとき: □
- またはを押すとき:の
- □、□、□、□ を押すとき: □

メニュー操作の表記について

メインメニュー操作やメニュー操作は、簡略化した表記方法で説明しています。

メインメニュー操作



メインメニュー項目を選んで ■(選択)を押す操作を繰り返す ことを示す

メニュー操作



「選択」について

項目や文字列の選択画面などで目的の位置にカーソルを移動させて ・ (選択)を押すことを、この取扱説明書では「選択」と表記します。

「選んで」について

項目や文字列の選択画面などで目的の位置にカーソルを移動させることを、この取扱説明書では「選んで」と表記します。

主に、項目にカーソルを移動させた後、図 または 図 で操作を行うときに使用しています。

はじめに2
お買い上げ品の確認i
機能の探しかた iv
本書の記載パターンvi
表記の見かたviii
目次 x
安全上のご注意 xiii
お願いとご注意 xx
本機の比吸収率(SAR)について xxvii
Safety Precautions xxix
General Notes xxxvi
SAR Certificationxl
European RF Exposure
Informationxli

準備/基礎知識

本	□機を使う準備 1-2
含	舒部の名称と機能1-3
U	ISIM カードのお取り扱い1-6
冒	討池パックと充電器のお取り扱い 1-7
冒	『源を入れる/切る1-11
É	1分の電話番号など
	(オーナー情報)の確認/編集 1-11
挊	fち運ぶときのご注意
	(ボタンのロック)1-12
~	?ナーについて 1-13
踞	証番号の取り扱い1-14
仴	列な機能1-16

2 共通機能/共通操作

共通機能と共通操作について 2-2
機能の呼び出しかた2-3
着信時の動作の設定2-5
待受画面 2-7
文字入力2-8
ユーザ辞書2-13
電話帳2-14
便利な機能2-18

3 電話

通話方法とオプションサービスに
ついて
音声電話
TV コール3-5
お気に入り3-7
緊急電話発信3-8
簡易留守録 3-9
着信拒否3-10
通話履歴/ランキング3-11
通話時間/通話料金/
データ通信量などの確認 3-13
日本から海外へ電話をかける3-14
海外での利用(世界対応ケータイ)3-14
オプションサービス3-15
便利な機能3-21

4メール

メールについて	. 4-2
E メールアドレスの登録/変更	. 4-3
メール作成・送信	. 4-3
メール受信・確認/返信/転送	. 4-8
メールの利用	4-12
メールのフォルダ管理	4-15
便利な機能	4-17

5 インターネット

インターネットについて	5-2
Yahoo! ケータイ	5-3
PC サイトの閲覧	5-4
情報画面の操作	5-6
ブックマーク/画面メモ	5-8
便利な機能	5-9

6 テレビ

テレビについて 6-7	2
テレビ利用時のご注意 6-5	3
チャンネルを設定する(エリア設定)6-	3
テレビ視聴6-/	4
テレビ視聴中の着信6-	6
番組の録画/再生 6-7	7
录画/視聴の予約6-	9
更利な機能6-1	0

7 カメラ/静止画編集

カメフ/静止囲編集について	/
静止画撮影	7-3
動画撮影	7-8
静止画加工フ	-11
フォトライブラリ7	-12
便利な機能	-13

8 メディアプレイヤー

メディアプレイヤーについて	8-2
音楽/動画のダウンロード	8-3
音楽再生	8-3
動画再生	8-5
プレイリスト	8-8
ストリーミング	8-8
便利な機能 8	3-1C

9 エンタテイメント

エンタテイメントについて	9-2
S! アプリ	9-3
S! 速報ニュース	9-3
無料コンテンツ	9-5
S! コンテンツストア	9-5
S! 情報チャンネル	9-5
ブックサーフィン [®]	9-6
便利な機能	9-7

10 ツール

ツールについて10-2
アラーム10-3
カレンダー10-4
予定リスト10-6
UV チェッカー10-7
ストップウォッチ10-7
世界時計10-7
おやすみタイマー10-8
電卓 10-8
メモ帳10-9
バーコードリーダー10-9
通貨・単位換算10-11
割り勘ツール10-12
ボイスレコーダー10-12
ドキュメントビューア10-13
見せかけ着信10-14
英和辞書/和英辞書10-15
便利な機能 10-15

11 セキュリティ

セキュリティ機能について11-2
暗証番号の変更 11-3
本機のロック11-3
機能別のロック11-5
お買い上げ時の状態に戻す
(メモリ消去/リセット)11-6

12 データフォルダ/メモリ

データフォルダについて	12-2
ファイルの確認	12-3
ファイル/フォルダの管理	12-6
メモリカード	12-8
メモリ容量を確認する 1	2-10
便利な機能1	2-11

13 通信/バックアップ

通信/バックアップについて	13-2
赤外線通信	13-3
USB 接続	13-5
メモリカードバックアップ	13-6
S! 電話帳バックアップを利用する	13-8
便利な機能1	3-10

14 カスタマイズ

本体機能の設定 14-2
音/バイブレータ/
—
着信ライトの設定 14-4
画像/文字表示の設定14-5
マナーモードの設定14-7
通話の設定14-7
電話帳の設定14-13
メールの設定14-13
インターネットの設定 14-18

目次

テレビの設定	14-2
カメラの設定	14-23
メディアプレイヤーの設定	14-25
エンタテイメントの設定	14-26
セキュリティの設定	14-27
メモリの設定	14-28
外部接続の設定	14-29

15 資料/付録

故障かな?と思ったら	15-2
水抜きのしかた	15-6
端子キャップの取り付けかた	15-7
ソフトウェアを更新する	15-8
機能一覧	15-8
文字入力用ボタン一覧	.15-14
記号一覧	.15-15
絵文字一覧	.15-16
メモリ容量一覧	.15-17
主な仕様	.15-17
保証とアフターサービス	15-22
索引	15-23
目的別索引	.15-29
便利な機能索引	.15-31
お問い合わせ先一覧	15-32

安全上のご注意

で使用の前に、この「安全上のご注意」をよくお読みのうえ、正しく お使いください。また、お読みになったあとは大切に保管してくだ さい。

- ここに示した注意事項は、お使いになる人や、他の人への危害、 財産への損害を未然に防ぐための内容を記載していますので、必 ずお守りください。
- ●本製品の故障、誤動作または不具合などにより、通話などの機会を逸したために、お客様、または第三者が受けられた損害につきましては、当社は責任を負いかねますのであらかじめご了承ください。

次の表示の区分は、表示内容を守らず、誤った使用をした場合に生 じる危害や損害の程度を説明しています。内容をよく理解したうえ で本文をお読みください。

危険

この表示は、取り扱いを誤った場合、「死亡または 重傷* ¹ を負う危険が切迫して生じることが想定される」内容です。



この表示は、取り扱いを誤った場合、「死亡または 重傷**¹ を負う可能性が想定される」内容です。



この表示は、取り扱いを誤った場合、「軽傷*2 負う可能性が想定される場合および物的損害*3の みの発生が想定される」内容です。

- ※ 1 重傷とは、失明・けが・高温やけど・低温やけど(体温より高い温度の発熱体を長時間肌にあてていると紅斑、水疱などの症状を起こすやけど)・感電・骨折・中毒などで、後遺症が残るものおよび治療に入院や長期の消除を要するものをさします。
- ※2 軽傷とは、治療に入院や長期の通院を要さない、けが・やけど・ 感電などをさします。
- ※3物的損害とは、家屋・家財および家畜・ペットなどにかかわる拡大損害をさします。

次の絵表示の区分は、お守りいただく内容を説明しています。内容 をよく理解したうえで本文をお読みください。

禁止	禁止(してはいけないこと)を示します。
分解禁止	分解してはいけないことを示します。
水濡れ禁止	水がかかる場所で使用したり、水に濡らし たりしてはいけないことを示します。
濡れ手禁止	濡れた手で扱ってはいけないことを示します。
Q 指示	指示に基づく行為の強制(必ず実行していただくこと)を示します。
B=C 電源ブラグ を抜く	プラグをコンセントから抜いていただくことを 示します。

本機、電池パック、USIM カード、充電器 (オブション品)、メモリカード (オプション品) の取り扱いについて (共通)



本機に使用する電池パック·充電器 (オプション品) は、 ソフトバンクが指定したものを使用してください。



指定品以外のものを使用した場合は、電池パックの漏液・発熱・破裂・発火や、充電器の発熱・発火・故障などの原因となります。

指示

分解・改造・ハンダ付けなどお客様による修理をしないでください。



分解禁止

火災・けが・感電などの事故または故障の原因となります。また、電池パックの漏液・発熱・破裂・発火などの原因となります。

電話機の改造は電波法違反となり、罰則の対象となります。

本機内部・電池パック・充電器を濡らさないでください。



水やペットの尿などの液体が入ったときに、濡れたまま放置したり、濡れた電池パックを充電すると、発熱・水濡れ禁止感電・火災・けが・故障などの原因となります。 使用場所、取り扱いにご注意ください。

高温になる場所(火のそば、暖房器具のそば、直射日 光の当たる場所、炎天下の車内など)で充電・使用・ 放置しないでください。



禁止

機器の変形・故障や電池パックの漏液・発熱・発火・破裂の原因となります。また、ケースの一部が熱くなり、 やけどなどの原因となることがあります。 本機に電池パックを取り付けたり、充電器を接続する際、うまく取り付けや接続ができないときは、無理に行わないでください。電池パックや端子の向きを確かめてから、取り付けや接続を行ってください。



電池パックを漏液・発熱・破裂・発火させるなどの原因となります。



本機・電池パック・充電器を、加熱調理機器(電子レン ジなど)・高圧容器(圧力釜など)の中に入れたり、電 磁調理器(IH 調理器)の上に置いたりしないでください。



電池パックの漏液・発熱・破裂・発火や、本機と充電 器の発熱・発煙・発火・故障などの原因となります。

プロパンガス、ガソリンなどの引火性ガスや粉塵の発生する場所(ガソリンスタンドなど)では、必ず事前に本機の電源をお切りください。また、充電もしないでください。



本機の熱でガスに引火する恐れがあります。 プロパンガス、ガソリンなど引火性ガスや粉塵の発生 する場所で使用すると、爆発や火災などの原因となり ます。

落としたり、投げたりして、強い衝撃を与えないでく ださい。



電池パックの漏液・発熱・破裂・発火や火災・感電・ 故障などの原因となります。

禁止

使用中、充電中、保管時に、異音・発煙・異臭など、 今までと異なることに気づいたときは、次の作業を行っ てください。



- 1 コンセントから充電器を持ってプラグを抜いてくだ さい。
- 2 本機の電源を切ってください。
- 3 やけどやけがに注意して、電池パックを取り外して ください。

異常な状態のまま使用すると、火災や感電などの原因 となります。

充電端子や外部接続端子に水やペットの尿などの液体や導 雷性異物(鉛筆の芯や金属片、金属製のネックレス、ヘア ピンなど) が触れないようにしてください。また内部に入 れないようにしてください。



ショートによる火災や故障などの原因となります。



ぐらついた台の上や傾いた所など、不安定な場所に置 かないでください。



落下して、けがや故障などの原因となります。バイブ レータ設定中や充電中は、特にご注意ください。

乳幼児の手の届かない場所に保管してください。 誤って飲み込んだり、けがなどの原因となります。

けがなどの原因となります。



子供が使用する場合は、保護者が取り扱い方法を教え てください。使用中においても、指示どおりに使用し ているかをご注意ください。



電池パックの取り扱いについて



電池パックのラベルに記載されている表示により、電池の種類を確 認した上で、ご利用・処分をしてください。

表示	電池の種類
Li-ion00	リチウムイオン電池

火の中に投下しないでください。



電池パックを漏液・破裂・発火させるなどの原因とな ります。

釘を刺したり、ハンマーでたたいたり、踏みつけたり、 強い衝撃を与えないでください。



雷池パックを漏液・発熱・破裂・発火させるなどの原 因となります。



電池パックの端子に、針金などの金属類を接触させな いでください。また、導電性異物(鉛筆の芯や金属片、 金属製のネックレス、ヘアピンなど) と一緒に電池パッ クを持ち運んだり保管したりしないでください。



電池パックを漏液・発熱・破裂・発火させるなどの原 因となります。

電池パック内部の液が眼の中に入ったときは、こすら ず、すぐにきれいな水で洗い流し、ただちに医師の診 察を受けてください。



失明などの原因となります。

χV



電池パック内部の液が皮膚や衣服に付着した場合は、 ただちに本機の使用をやめ、きれいな水で洗い流して ください。



皮膚に傷害を起こすなどの原因となります。

所定の充電時間を超えても充電が完了しない場合は、 充電を中止してください。



電池パックを漏液・発熱・破裂・発火させるなどの原 因となります。

指示

電池パックの使用中・充電中・保管時に、異臭・発熱・ 変色・変形など、今までと異なることに気づいたときは、 やけどやけがに注意して雷池パックを取り外し、さら に火気から遠ざけてください。



異常な状態のまま使用すると、電池パックを漏液・発熱・ 破裂・発火させるなどの原因となります。



不要になった電池パックは、一般のゴミと一緒に捨て ないでください。



端子にテープなどを貼り、個別回収に出すか、最寄り の「ソフトバンクショップ |へお持ちください。 電池を分別している市町村では、その規則に従って処 理してください。

本機の取り扱いについて



自動車、バイク、自転車などの乗り物の運転中には使 用しないでください。



交通事故の原因となります。

乗り物を運転しながら携帯電話を使用することは、法律 で禁止されており、罰則の対象となります。運転者が使 用する場合は、駐停車が禁止されていない安全な場所に 止めてからご使用ください。

高精度な制御や微弱な信号を取り扱う電子機器の近く では、本機の電源を切ってください。



電子機器が誤動作するなどの影響を与える場合があります。 ※ ご注意いただきたい電子機器の例

補聴器・植込み型心臓ペースメーカ・植込み型除細動 器・その他の医用電気機器・火災報知器・自動ドア・ その他の自動制御機器など

本機の電波により運航の安全に支障をきたす恐れがあ るため、航空機内では電源をお切りください。



機内で携帯電話が使用できる場合は、航空会社の指示 に従い適切にご使用ください。

心臓の弱い方は、着信時のバイブレーション(振動) や着信音量の設定に注意してください。



心臓に影響を与える恐れがあります。

屋外で使用中に雷が鳴りだしたら、ただちに電源を切っ て屋内などの安全な場所に移動してください。

赤外線ポートを目に向けて送信しないでください。 目に影響を与える可能性があります。

落雷や感電の原因となります。



車両電子機器に影響を与える場合は使用しないでください。 本機を自動車内で使用すると、車種によりまれに車両電 子機器に影響を与え、安全走行を損なう恐れがあります。



本機の使用により、皮膚に異常が生じた場合は、ただ ちに使用をやめて医師の診察を受けてください。



本機では材料として金属などを使用しています。お客 様の体質や体調によっては、かゆみ・かぶれ・湿疹な どが生じることがあります。

本機で使用している材料については、「使用材料、表面 処理 I(♠P.15-18)を参照してください。

本機に磁気カードなどを近づけたり、挟んだりしない でください。



キャッシュカード・クレジットカード・テレホンカード・ フロッピーディスクなどの磁気データが消えてしまう ことがあります。



ストラップなどを持って本機をふり回さないでください。



本人や周りの方に当ったり、ストラップが切れたりし て、けがなどの事故や故障および破損の原因となります。

本機を長時間で使用になる場合、特に高温環境では熱 くなることがありますので、ご注意ください。



長時間肌にふれたまま使用していると、低温やけどに なる恐れがあります。



着信音が鳴っているときや、本機でメロディを再生してい るときなどは、スピーカーに耳を近づけないでください。 難聴になる可能性があります。



デジタルテレビを視聴するときは、充分明るい場所で、画 面からある程度の距離を空けてご使用ください。



視力低下につながる可能性があります。

イヤホンを使用するときは音量に気をつけてください。 長時間使用して難聴になったり、突然大きな音が出て 耳をいためたりする原因となります。



充電器 (オプション品) の取り扱いについて



充電中は、布や布団でおおったり、包んだりしないでください。 熱がこもって火災や故障などの原因となります。



指定以外の電源・電圧で使用しないでください。

指定以外の電源・電圧で使用すると、火災や故障など の原因となります。



• AC アダプタ(オプション品) AC100V~240V(家庭用 AC コンヤント専用)

長時間使用しない場合は、充電器を持ってプラグをコ ンセントから抜いてください。



を抜く

感電・火災・故障の原因となります。

万一、水やペットの尿などの液体が入った場合は、た だちに充電器を持ってコンセントからプラグを抜いて ください。



感雷・発煙・火災の原因となります。

プラグにほこりがついたときは、充電器を持ってプラグを コンセントから抜き、乾いた布などでふき取ってください。 火災の原因となります。



充電器をコンセントに差し込むときは、充電器のプラ グや端子に導電性異物(鉛筆の芯や金属片、金属製の ネックレス、ヘアピンなど)が触れないように注意して、 確実に差し込んでください。



感電・ショート・火災などの原因となります。

濡れた手で充電器のプラグを抜き差ししないでください。 感雷や故障などの原因となります。



雷が鳴り出したら、充電器には触れないでください。 感電などの原因となります。



お手入れの際は、コンセントから、必ず充電器を持っ てプラグを抜いてください。



感雷などの原因となります。

電源プラグ

を抜く

充電器をコンセントから抜くときは、コードを引っ張 らず、充電器を持ってプラグを抜いてください。



コードを引っ張るとコードが傷つき、感電や火災など の原因となります。

充電器をコンセントに接続しているときは、引っ掛け るなど強い衝撃を与えないでください。

けがや故障の原因となります。



医用電気機器近くでの取り扱いについて

● ここで記載している内容は、「医用電気機器への電波の影響を防止するための携帯電話端末等の使用に関する指針」(電波環境協議会 [平成9年4月])に準拠、ならびに「電波の医用機器等への影響に関する調査研究報告書」(平成13年3月「社団法人電波産業会」)の内容を参考にしたものです。



植込み型心臓ペースメーカおよび植込み型除細動器を 装着されている場合は、ペースメーカ等の装着部位か ら22cm以上離して携行および使用してください。



電波により植込み型心臓ペースメーカおよび植込み型除細動器の作動に影響を与える場合があります。

自宅療養など医療機関の外で、植込み型心臓ペースメーカおよび植込み型除細動器以外の医用電気機器を使用される場合には、電波による影響について個別に医用電気機器メーカなどに確認してください。



電波により医用電気機器の作動に影響を与える場合があります。

医療機関などでは、以下を守ってください。本機の電波により医用電気機器に影響を及ぼす恐れがあります。



- 手術室・集中治療室(ICU)・冠状動脈疾患監視病室 (CCU) には、本機を持ち込まないでください。
- ●病棟内では、本機の電源を切ってください。電源が 自動的に入る設定(アラーム機能など)をしている 場合は、設定を解除してから電源を切ってください。

- ロビーなど、携帯電話の使用を許可された場所であっても、近くに 医用電気機器があるときは本機の電源を切ってください。
- 医療機関が個々に使用禁止、持ち込み禁止などの場所を定めている場合は、その医療機関の指示に従ってください。

満員電車などの混雑した場所にいるときは、本機の電源を切ってください。付近に植込み型心臓ペースメーカおよび植込み型除細動器を装着されている方がいる可能性があります。電源が自動的に入る設定(アラーム機能など)をしている場合は、設定を解除してから電源を切ってください。



電波により、植込み型心臓ペースメーカおよび植込み 型除細動器が誤動作するなどの影響を与える場合があ ります。

お願いとご注意

ご利用にあたって

- 事故や故障などにより本機またはメモリカードに登録したデータ (電話帳、画像、サウンドなど)が消失・変化した場合の損害に つきましては、当社は責任を負いかねますのであらかじめご了承 ください。大切な電話帳などのデータは、控えをとっておかれる ことをおすすめします。
- 本機は、電波を利用しているため、特に屋内や地下街、トンネル 内などでは電波が届きにくくなり、通話が困難になることがあり ます。また、通話中に電波状態の悪い場所へ移動すると、通話が 急に途切れることがありますので、あらかじめご了承ください。
- 本機を公共の場所でご利用いただくときは、周りの方の迷惑にならないようにご注意ください。
- 本機は電波法に定められた無線局です。したがって、電波法に基づく検査を受けていただくことがあります。あらかじめご了承ください。
- 一般の電話機やテレビ、ラジオなどをお使いになっている近くで本機を使用すると、雑音が入るなどの影響を与えることがありますので、ご注意ください。
- 傍受(ぼうじゅ)にご注意ください。

本機は、デジタル信号を利用した傍受されにくい商品ですが、電波を利用している関係上、通常の手段を超える方法をとられたときには第三者が故意に傍受するケースもまったくないとは言えません。この点をご理解いただいたうえで、ご使用ください。

- 傍受とは

無線連絡の内容を第三者が別の受信機で故意または偶然に受信することです。

自動車内でのご使用にあたって

- 運転中は、本機を絶対にご使用にならないでください。
- 本機をご使用になるために、禁止された場所に駐停車しないでください。
- 本機を車内で使用したときは、自動車の車種によって、まれに車 両電子機器に影響を与えることがありますので、ご注意ください。

航空機の機内でのご使用について

本機の電波により運航の安全に支障をきたす恐れがあるため、航空機内では電源をお切りください。
 機内で携帯電話が使用できる場合は、航空会社の指示に従い適切にご使用ください。

機能制限について

- 機種変更または解約した場合、本機では次の機能が利用できなくなります。
 - カメラ
 - メディアプレイヤー
 - S! アプリ
 - テレビ
- 本機を長期間お使いにならなかった場合、上記の機能が利用できなくなる可能性があります。

お取り扱いについて

- 本機の電池パックを長い間外していたり、電池残量のない状態で 放置したりすると、お客様が登録、設定した内容が消失または変 化してしまうことがありますので、ご注意ください。なお、これ らに関しまして発生した損害につきましては、当社は責任を負い かねますので、あらかじめご了承ください。
- 本機は5~35℃の範囲でご使用ください。極端な高温や低温環境、直射日光の当たる場所でのご使用、保管は避けてください。
- カメラ部分に、直射日光が長時間当たると、内部のカラーフィルターが変色して、映像が変色することがあります。
- 本機を落下させたり衝撃を与えたりしないでください。
- お手入れは、乾いた柔らかい布などで拭いてください。また、アルコール、シンナー、ベンジンなどを用いると色があせたり、文字が薄くなったりすることがありますので、で使用にならないでください。
- 本機は精密部品で作られた無線通信装置です。絶対に分解、改造はしないでください。
- 本機のディスプレイを堅いものでこすったり、傷つけないように で注意ください。
- ステレオヘッドフォンの中には開放型のものがあり、音が外に漏れることがあります。周りの方の迷惑にならないようにご注意ください。
- 本機に無理な力がかかるような場所には置かないでください。故障やけがの原因となります。
 - 本機をズボンやスカートのポケットに入れたまま、しゃがみこんだり座席や椅子などに座らないでください。特に、厚い生地の衣服のときはご注意ください。
 - かばんなどに入れるときは、重たいものの下にならないよう にご注意ください。
- 本機の充電端子/外部接続端子に指定品以外の商品は取り付けないでください。誤動作を起こしたり、本機を傷めることがあります。

 電池パックを取り外すときは、必ず本機の電源を切ってから取り 外してください。データの登録やメールの送信などの動作中に電 池パックを取り外さないでください。データの消失、変化、破損 などの恐れがあります。

ボタン操作面がふくらむ現象について

- 電池カバーを取り付けた場合や、急激な気圧の変化(高山地帯や 飛行機の搭乗中など)によりボタン操作面がふくらむことがあり ますが、異常ではありません。しばらくすると元に戻ります。
- 空気が本機内部に入ったときは、端子キャップを開けることでも 空気が抜けます。
- 電池カバーを閉じるときは、外部から空気が入らないようにゆっくりと閉じてください。
- ボタン操作面のふくらんだ部分を強く押したり、先のとがったもので傷つけないようにしてください。しばらくすると元に戻ります。

防水について

本機の防水性能

本機は、端子キャップをしっかりと閉じ、電池カバーを取り付けてロックした状態で、IPX5(旧 JIS 保護等級 5)*1、IPX7(旧 JIS 保護等級 7)*2 相当の防水性能があります。

- ※ 1 IPX5 相当: 内径 6.3mm の注水ノズルを使用し、約3m の距離から約12.5 リットル/分の水を最低3分間注水する条件であらゆる方向から噴流を当てても、電話機としての機能を保つことを意味します。
- ※2 IPX7 相当:常温で水道水、かつ静水の水深 1 m の水槽に本機を静かに沈め、約30分間水底に放置しても、電話機内部に浸水せず、電話機としての機能を保つことを意味します。
- 実際の使用にあたって、すべての状況での動作を保証するものではありません。お客様の取り扱いの不備による故障と認められたときは、保証の対象外となりますのでご了承ください。

ご使用にあたっての注意事項

- 電池カバーは確実にロックし、端子キャップはしっかりと閉じてください。接触面に細かいゴミ(髪の毛1本、砂粒1粒、微細な繊維など)がわずかでも挟まると、浸水の原因となります。
- 端子キャップや電池カバーが開いている状態で水などの液体がかかった場合、内部に液体が入り、感電や故障の原因となります。そのまま使用せずに電源を切り、電池パックを外してください。
- 本機が濡れているときは、ボタン操作面やヒンジ部などの隙間から水分が入り込んでくる場合がありますので、水抜きをし、乾いたきれいな布でふき取ってください。濡れたまま放置しないでください。

- 雨がかかっている最中、電話機に水滴がついているとき、または、手や本機が濡れているときは、内部に浸水することを防ぐため、電池カバーや端子キャップの開閉は絶対にしないでください。完全に乾かした後にゆっくりと電池カバーや端子キャップの開閉をしてください。万一水などの液体が内部に入った場合は、そのまま使用せずに電源を切り、電池パックを外した状態で「ソフトバンクショップ」までご連絡ください。
- 端子キャップや電池カバーの周辺が濡れているときは、内部に 浸水することを防ぐため、完全に乾かした後にゆっくりとカ バーを開閉してください。
- 常温(5℃~35℃)の真水・水道水以外の液体につけないでください。

防水(水周りでのご使用)に関するご注意

- 本機に真水や水道水以外の液体(石けん、洗剤、入浴剤を含んだ水/海水/プールの水/温泉/熱湯/薬品/汗など)をかけたり、つけたりしないでください。また、砂や泥が付着しないようにしてください。
- 万一本機に真水や水道水以外の液体が付着してしまった場合は、 直ちに水で洗い流してください。やや弱めの水流(6リットル/ 分以下、常温(5℃~35℃)の水道水)で蛇口やシャワーより 約10cm離れた位置で洗えます。電池カバーを取り付けてロッ クした状態で、外部接続端子キャップが開かないように押さえた まま、プラシやスポンジなどは使用せず手で洗ってください。
- 湯船やプールなどにつけないでください。また、水中で使用(本機の開閉やキー操作を含む)しないでください。
- 本機は耐水圧設計ではありません。水道やシャワーなどで強い流水(6リットル/分を超える)を当てたり、水面に落下させたり、水中に沈めたりしないでください。
- 風呂場など湿気の多い場所には、長時間放置しないでください。
 また、風呂場で長時間利用しないでください。

- 本機は温度:5℃~35℃、湿度:35%~90%の範囲でで使用ください(風呂場などでの一時的な使用に限り、温度36℃~40℃の範囲で可能)。
- 本機は耐熱設計ではありません。サウナでは使用しないでください。また、ドライヤーなどの温風はあてないでください。
- コンロの脇や冷蔵庫の中など極端に高温・低温になるところに置かないでください。
- マイク、レシーバー、スピーカー部の穴に水が入ったときは、一時的に音量が小さくなることがあります。十分に水抜きと乾燥を行ったうえでご使用ください。乾燥後は、通常の音量に戻ります。
- 砂浜、砂場などの砂の上に直接置かないでください。レシーバー、 スピーカーなどに砂が入り、音が小さくなる恐れがあります。
- 結露防止のため、寒い場所から風呂場などへは本機が常温になってから持ち込んでください。万一結露が発生したときは、取れるまで常温で放置してください。
- 本機は水に浮きません。
- 強い雨の中では使用しないでください。
- 濡れたまま放置しないでください。寒冷地で凍結するなど、故障の原因となります。

防水性能を維持するためのご注意

- 落下させるなど、本体に強い衝撃を与えたり、マイク、レシーバー、 スピーカーなどを綿棒やとがったものでつつかないでください。
- 端子キャップや電池カバーのゴムパッキンは防水性能を維持する うえで重要な役割を負っています。はがしたり、傷つけたりしないでください。また、ゴミが付着しないようにしてください。
- 端子キャップのすき間に、先のとがったものを差し込まないでください。ゴムパッキンが傷つき、浸水の原因となることがあります。
- イヤホンマイクや充電器などを、端子キャップが反対方向に長時間開くように挿入しないでください。端子キャップが変形してしまうなどして、防水性能が維持できません。

- 端子キャップのゴムパッキンが傷ついたり、変形したときは、ゴムパッキンを交換してください。
- 防水性能を維持するため、ゴムパッキンは異常の有無にかかわらず、2年ごとに交換することをおすすめします。 ゴムパッキンの交換については、「ソフトバンクショップ」までご連絡ください。
- 電池カバーや端子キャップに劣化、破損があるときは、防水性能を維持できません。その場合は、「ソフトバンクショップ」までご連絡ください。

充電時のご注意

- 充電器・オプション品は、防水対応していません。屋外や風呂場、 洗面所など湿気の強い場所や水のかかる可能性のある場所では使用しないでください。火災・感電・故障の原因となります。また、 充電しないときでも、風呂場などに持ち込まないでください。
- 本機が濡れているときは絶対に充電しないでください。感電や回路のショートなどによる火災・故障の原因となります。
- 外部接続端子の端子キャップを開いて充電したときには、充電後 しっかりと端子キャップを閉じてください。
- 濡れた手で充電器に触れないでください。感電の原因となります。
- 充電器は、水周りで使用しないでください。火災・感電の原因と なります。

本機が濡れたときの対処は、「水抜きのしかた」(�P.15-6)を参照してください。

端子キャップが外れたときの対処は、「端子キャップの取り付けかた」 (�P.15-7)を参照してください。

UV チェッカーに関する注意事項

- UV チェッカーを使うときは、正しく測定するため、紫外線センサーを2~3回太陽に向けてください。
- UV チェッカーは天気や周りの建物に影響されるため、正しく測定できないことがあります。
- UV チェッカーは正しく測定できないことがありますので、参考としてご利用ください。
- 紫外線センサーが汚れている(指紋や異物が付いているなど)場合、正しく測定できないことがあります。
- 急激な温度変化によって、紫外線センサーが破損することがありますのでご注意ください。
- 落下させるなど、本体に強い衝撃を与えた場合、紫外線センサー が動作しないことがあります。
- 紫外線センサーが露出された(本機を開いた)状態で、強い日差 しや紫外線の中に、放置しないでください。破損することがあり ますのでご注意ください。
- 本機を閉じた状態では UV チェッカーが動作しません。本機を開いた状態で使用してください。
- 連続で UV チェッカーを使用すると、UV チェッカーが正常に動作しないことがあります。
- 長時間の使用によって、紫外線センサーの周辺が変色することがあります。故障ではありません。
- 紫外線センサーは水の中では動作できません。
- UV チェッカーと実際の紫外線量が異なることがあります。肌を紫外線から守るため、日焼け止めクリームを使用するなどしてください。
- UV チェッカーで「弱め(安心して外で過ごせます。)」として表示されたときでも、安全であるという意味ではありません。
- 周囲の環境および状況によって、UV チェッカーの計測時間が変わることがあります。

著作権などについて

音楽、映像、コンピュータ・プログラム、データベースなどは著作 権法により、その著作物および著作権者の権利が保護されています。 こうした著作物を複製することは、個人的にまたは家庭内で使用す る目的でのみ行うことができます。上記の目的を超えて、権利者の 了解なくこれを複製(データ形式の変換を含む)、改変、複製物の譲 渡、ネットワーク上での配信などを行うと、「著作権侵害」「著作者 人格権侵害 として損害賠償の請求や刑事処罰を受けることがあり ます。本製品を使用して複製などをなされる場合には、著作権法を 遵守のうえ、適切なご使用を心がけていただきますよう、お願いい たします。また、本製品にはカメラ機能が搭載されていますが、本 カメラ機能を使用して記録したものにつきましても、上記と同様の 適切なご使用を心がけていただきますよう、お願いいたします。 本機に搭載のソフトウェアは著作物であり、著作権、著作者人格権 などをはじめとする著作者等の権利が含まれており、これらの権利 は著作権法により保護されています。ソフトウェアの全部または一 部を複製、修正あるいは改変したり、ハードウェアから分離したり、 逆アセンブル、逆コンパイル、リバースエンジニアリング等は行わ ないでください。第三者にこのような行為をさせることも同様です。

登録商標について

- 下記一件または複数の米国特許またはそれに対応する他国の特許権に基づき、QUALCOMM社よりライセンスされています。
 - Licensed by QUALCOMM Incorporated under one or more of the following United States Patents and/or their counterparts in other nations:
 - 4,901,307 5,490,165 5,056,109 5,504,773 5,101,501 5,506,865 5,109,390 5,511,073 5,228,054 5,535,239 5,267,261 5,544,196 5,267,262 5,568,483 5,337,338 5,600,754 5,414,796 5,657,420 5,416,797 5,659,569 5,710,784 5,778,338

- TV コール、S! メール、PC サイトブラウザ、S! 速報ニュース、S! アブリ、S! 電話帳パックアップ、デコレメール、楽デコ、フィー リングメール、S! 情報チャンネル、お天気アイコン、S-1 バトル、 コンテンツ得パック、選べるかんたん、ともだちメール、タダデコ、タダコミ、タダゲーム、タダ歌ばんはソフトバンクモバイル 株式会社の登録商標または商標です。
- SOFTBANK およびソフトバンクの名称、ロゴは日本国およびその他の国におけるソフトバンク株式会社の登録商標または商標です。
- 「Yahoo!」および「Yahoo!」「Y!」のロゴマークは、米国 Yahoo! Inc. の登録商標または商標です。
- This product contains ACCESS Co., Ltd.'s NetFront Internet browser software.NetFront is a trademark or registered trademark of ACCESS Co., Ltd. in Japan and in other countries.

 AGCESS NetFront*
- 本製品のソフトウェアの一部に、Independent JPEG Group が開発したモジュールが含まれています。
- THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (i) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NONCOMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, LLC. SEE HTTP://WWW.MPEGLA.COM.
- Contains Macromedia[®] Flash [®] Flash Lite[™] technology by Adobe Systems Incorporated.

- Copyright © 1995-2005 Adobe Systems Incorporated. All rights reserved.
- Macromedia, Flash, Macromedia Flash, and Macromedia Flash Lite are trademarks or registered trademarks of Adobe Systems Incorporated in the United States and other countries.
- この製品では、株式会社アプリックスが Java™ アプリケーションの実行速度が速くなるように設計した JBlend™ が搭載されています。
- Powered by JBlend™ Technology.JBlend および JBlend ロゴマークは、株式会社アプリックスの商標ま たは登録商標です。



- Powered by JBlend™, ©1997-2006 Aplix Corporation. All rights reserved.
- JBlend および JBlend に関連する商標は、日本およびその他の 国における株式会社アプリックスの商標または登録商標です。
- Java および Java に関連する商標は、米国およびその他の国における米国 Sun Microsystems, Inc. の商標または登録商標です。



- 「着うた®」「着うたフル®」は、株式会社ソニー・ミュージック エンタテイメントの登録商標です。
- microSD™、microSDHC™ は SD アソシエーションの商標です。



- QR コードは株式会社デンソーウェーブの登録商標です。
- Powered by SwiftDecoder™ Copyright ©1996-2007, Omniplanar, Inc. All Rights Reserved.
- Windows、Windows Media は米国 Microsoft Corporation の米国およびその他の国における登録商標です。

- 「BookSurfing」は株式会社セルシス、株式会社ボイジャー、株式会社インフォシティの登録商標です。
- Windows は Microsoft Windows operating system の略称 として表記しています。
- その他の記載している会社名、製品名は各社の登録商標または商標です。

本機の比吸収率(SAR)について

本機の携帯電話機は、国が定めた電波の人体吸収に関する技術基準に適合しています。

この技術基準は、人体頭部のそばで使用する携帯電話機などの無線機器から送出される電波が人間の健康に影響を及ぼさないよう、科学的根拠に基づいて定められたものであり、人体頭部に吸収される電波の平均エネルギー量を表す比吸収率(SAR: Specific Absorption Rate)について、これが2 W/kg[®]の許容値を超えないこととしています。この許容値は、使用者の年齢や身体の大きさに関係なく十分な安全率を含んでおり、世界保健機関(WHO)と協力関係にある国際非電離放射線防護委員会(ICNIRP)が示した国際的なガイドラインと同じ値になっています。すべての機種の携帯電話機は、発売開始前に、電波法に基づき国の技術基準に適合していることの証明(技術基準適合証明)を受ける必要があります。

この携帯電話機[840SC]も財団法人テレコムエンジニアリングセンターから技術基準適合証明を受けており、SARは 0.183 W/kg です。この値は、技術基準適合証明のために財団法人テレコムエンジニアリングセンターによって取得されたものであり、国が定めた方法に従い、携帯電話機の送信電力を最大にして測定された最大の値です。

個々の製品によってSARに多少の差異が生じることもありますが、いずれも許容値を満足しています。また、携帯電話機は、携帯電話基地局との通信に必要な最低限の送信電力になるよう設計されているため、実際に通話している状態では、通常 SAR はより小さい値となります。 SAR について、さらに詳しい情報をお知りになりたい方は、下記のホーケページをで参照ください。

総務省のホームページ

http://www.tele.soumu.go.jp/j/ele/index.htm

社団法人電波産業会のホームページ

http://www.arib-emf.org/

※ 技術基準については、電波法関連省令(無線設備規則第 14 条の 2)で規定されています。

「ソフトバンクのボディ SAR ポリシー」について

- * ボディ(身体) SAR とは:携帯電話機本体を身体に装着した状態で、携帯電話機にイヤホンマイク等を装着して連続通話をした場合の最大送信電力時での比吸収率(SAR)のことです。
- **比吸収率(SAR):6分間連続通話状態で測定した値を掲載しています。当社では、ボディSARに関する技術基準として、欧州における情報を掲載しています。詳細は「欧州における電波ばく露の影響に関する情報」をご参照ください。
- ***身体装着の場合:一般的な携帯電話の装着法として身体から 1.5 センチに距離を保ち携帯電話機の背面を身体に向ける位置で 測定試験を実施しています。電波ばく露要件を満たすためには、 身体から 1.5 センチの距離に携帯電話を固定出来る装身具を使 用し、ベルトクリップやホルスター等には金属部品の含まれてい ないものを選んでください。

ソフトバンクモバイルのホームページからも内容をご確認いただけ ます。

http://www.softbankmobile.co.jp/ja/info/public/emf/emf02.html

「欧州における電波ばく露の影響に関する情報」

この携帯電話機「840SC」は無線送受信機器です。本品は国際指針の推奨する電波の許容値を超えないことを確認しています。この指針は、独立した科学機関である国際非電離放射線防護委員会(ICNIRP)が策定したものであり、その許容値は、使用者の年齢や健康状態にかかわらず十分に安全な値となっています。携帯電話機から送出される電波の人体に対する影響は、比吸収率(SAR: Specific Absorption Rate)という単位を用いて測定します。携帯機器における SAR 許容値は2W/kgで、身体に装着した場合のSAR の最高値は 0.183 W/kg*です。

SAR 測定の際には、送信電力を最大にして測定するため、実際に通話している状態では、通常 SAR はより小さい値となります。これは、携帯電話機は、通信に必要な最低限の送信電力で基地局との通信を行うように設計されているためです。世界保健機関は、モバイル機器の使用に関して、現在の科学情報では人体への悪影響は確認されていないと表明しています。また、電波の影響を抑えたい場合には、通話時間を短くすること、または携帯電話機を頭部や身体から離して使用することが出来るハンズフリー用機器の利用を推奨しています。。

さらに詳しい情報をお知りになりたい場合には世界保健機関のホームページをご参照ください。

世界保健機関のホームページ

http://www.who.int/emf(英文のみ)

※ 身体に装着した場合の測定試験は、FCC が定めた基準に従って 実施されています。値は欧州の条件に基づいたものです。

Safety Precautions

Read safety precautions before using handset.

- · Observe precautions to avoid injury to self or others, or damage to property.
- SoftBank is not liable for any damages resulting from use of this product.

These labels indicate the degree of risk from improper use.

Make sure you thoroughly understand their meanings before reading on.

<u> </u>	Great risk of death or serious injury 1 from improper use
Warning	Risk of death or serious injury*1 from improper use
Caution	Risk of injury ^{*2} or damage to property ^{*3} from improper use

- *1 "Serious injury" includes blindness, wounds, low/high heat burns, electric shock, bone fractures, poisoning or other physical harm with aftereffects, or requiring hospitalization or ongoing hospital visits.
- *2 "Injury" includes wounds, burns, electric shock or other physical harm not requiring hospitalization or ongoing hospital visits.
- *3 "Damage to property" includes damage to home, furniture, livestock, pets, etc.

These symbols indicate prohibited or compulsory actions.

Make sure you thoroughly understand their meanings before reading on.

Prohibited	Prohibited actions		
Do Not Disassemble	Disassembly prohibited		
Avoid Liquids Or Moisture	Exposure to liquids prohibited		
Do Not Use Wet Hands	Use with wet hands prohibited		
Compulsory	Compulsory actions		
Disconnect Power Source	Unplug Charger from outlet		

Handset, Battery, USIM Card, Charger (Sold Separately) & Memory Card (Sold Separately)



Use specified battery and Charger (sold separately) only.



Non-specified equipment use may cause battery to leak. overheat, burst or ignite, and may cause Charger to overheat.

Compulsory

Do not disassemble, modify or solder handset or related hardware.

ignite, malfunction, etc.



Disassemble

May cause fire, injury, electric shock or malfunction. Battery may leak, overheat, burst or ignite. Modifying handsets is prohibited by the Radio Law and subject to a penalty.

Do not expose inside of the handset or related hardware to liquids.



Avoid Liquids Or Moisture

Do not leave handset or related hardware wet after exposure to water, pet urine, etc., and do not charge wet battery. May cause overheating, electric shock, fire, injury or malfunction. Use them in an appropriate place properly.

Do not charge battery in or expose handset or related hardware to extreme heat (e.g., near fire or sources of heat, in direct sunlight, inside vehicles, etc.).



May cause warping/malfunction; battery may leak, overheat, ignite or burst. Handset or related hardware may become hot to the touch. leading to burn injuries, etc.

Do not force battery/Charger into handset. Check the direction and retry.



Battery may leak, overheat, burst, ignite, etc.

Warning

Do not place handset, battery or Charger in/ on ovens, microwave ovens, pressure cookers, induction stoves or other cooking appliances.



Battery may leak, overheat, burst or ignite, Handset/Charger may overheat, emit smoke, ignite, malfunction, etc.

Keep handset off and Charger disconnected near gas stations or places with fire/explosion risk.



Handset use near petrochemicals or other flammables may cause fire/explosion.

To prevent fire or explosion, do not use handset near gas or fine particles (Coal, dust, metal, etc.).

Compulsory

Do not apply strong shocks or impacts.



Do not drop/throw handset or related hardware. Battery may leak, overheat, burst or ignite, resulting in fire, electric shock, malfunction, etc.

Prohibited

If there is unusual sound/odor, smoke or any other abnormality:



Continued use may cause fire, electric shock, etc.; grasp plug to disconnect Charger from connector.

Compulsory

Keep liquids (water, pet urine, etc.) or conductive material (pencil lead, metallic strip, metal jewelry, etc.) away from Charging terminals, External Device.



May cause short circuit, resulting in fire, malfunction, etc.



Caution

Do not place handset or related hardware on unstable surfaces.



Handset or related hardware may fall, resulting in injury. malfunction, etc.; be especially careful when Vibration is set or during Charge.

Keep handset and related hardware out of infants' reach.

Infants may choke from swallowing handset or related hardware or be injured, etc.



If your child is using handset and related hardware, explain all instructions and supervise usage.



Misuse may cause injury, etc.

Battery



Read battery label to confirm battery type; use/dispose of battery accordingly.

Display	Battery type		
Li-ion00	Lithium-ion		

Do not dispose of battery in fire.

Battery may leak, burst, ignite, etc.



Do not damage battery (with a nail, hammer, foot, etc.) or subject it to strong impacts or shocks.



Battery may leak, overheat, burst, ignite, etc.

Prohibited

Keep wire or other metal objects away from battery terminals. Do not carry/store battery with conductive material (pencil lead, metallic strip, metal jewelry, etc.).



Battery may leak, overheat, burst, ignite, etc.

If battery fluid gets in eyes, do not rub; rinse with water and consult a doctor immediately.



Eyes may be severely damaged.

May cause skin damage.



If battery fluid contacts skin or clothes. discontinue handset use and rinse with clean water immediately.



If battery does not charge properly, stop trying.

Battery may leak, overheat, burst, ignite, etc.



Compulsory

xxxi

If there is abnormal odor, excessive heat, discoloration or distortion, remove battery, being careful not to burn or injure yourself. Avoid fire sources.



Compulsory

Continued use may cause battery to leak, overheat, burst, ignite, etc.



Do not dispose of an exhausted battery with ordinary refuse.



Tape over battery terminals before disposal. Take battery to a SoftBank Shop, or follow the local disposal regulations.

Handset



Do not use handset while driving or cycling.





Prohibited

Phone use while driving or cycling is prohibited by law and subject to a penalty; park in a legal parking space beforehand. Turn handset power off near electronic devices that employ high precision control systems or weak signals.



May cause electronic malfunctions, etc. Be especially careful near the following devices:

Hearing aids, implanted pacemakers/defibrillators and other electronic medical equipment; fire alarms, automatic doors and other automatic control devices.

Because handset radio waves may impair aircraft operations, please power off handset while aboard.



When handset use aboard aircraft is allowed, please follow instructions of airline personnel.

Compulsory

Users with a heart condition should adjust ringtone Vibration and Volume as needed.



May cause heart damage.

If thunder is heard while outdoors, turn power off; find cover.



There is a risk of lightning strike or electric shock.

Do not look into Infrared Port during infrared transmissions.

Eyesight may be affected.



Do not use handset when it may affect a vehicle's electronic equipment.



Prohibited

Handset use inside vehicles may cause electronic equipment to malfunction, resulting in accidents.

If you experience any skin irritation associated with handset use, discontinue handset use and consult a doctor.



Metal and other materials may cause skin irritation, rashes, or itchiness depending on your physical condition.


Parts	Materials & Finishing			
Housing (upper)	PC/SPRAY			
Housing (lower)	PC+GF20%(STS INSERT)/SPRAY			
Housing (front)	PC+GF20%/SPRAY			
Housing (rear)	PC+GF20%/SPRAY			
Upper DECO	PC/SPRAY			
Keypad	PC/SPRAY			
Side Key	PC+POLYURETHANE/SPRAY			
Battery Cover	PC+GF20%/SPRAY			

Keep handset away from magnetic cards, etc.





Do not swing handset by strap.





Handset may become hot while in use, especially at high temperature.



Prolonged contact with skin may cause burn injuries.

Compulsory

Always maintain some distance from Speaker while ringtones, music or other handset sounds play.



Excessive volume may damage ears or hearing.

Prohibited

When view Digital TV, be sure to view in place with enough light and view from distance, otherwise it may cause decrease in vision.



Moderate handset volume when using Earphone Microphone.



Excessive volume may damage ears or hearing.

Compulsory

Charger (Sold Separately)



Do not cover/wrap Charger while charging.

 ${\it Charger \ may \ overheat, \ resulting \ in \ fire, \ malfunction, \ etc.}$



Use only the specified voltage.

Non-specified voltages may cause fire, malfunction, etc.

 AC Adapter (sold separately): AC 100V-240V (only for household wall sockets).



Prohibited

Leave Charger unplugged during periods of disuse; grasp plug to disconnect it.

May cause electric shock, fire or malfunction.



Disconnect Power Source

If liquids (water, pet urine, etc.) seep inside Charger, grasp plug from outlet and disconnect Charger immediately.



Disconnect Power Source

May cause electric shock, smoke/fire.

If plug is dusty, grasp it and disconnect Charger, then clean with a dry cloth.







Plug Charger firmly into the outlet, keeping the plug and Charger charging terminals away from conductive material (pencil lead, metallic strip, metal jewelry, etc.).



May cause electric shock, short circuit, fire, etc.

Do not touch Charger plug with wet hands.

May cause electric shock or malfunction, etc.



Do Not Use Wet Hands

Do not touch Charger if thunder is heard.

May cause electric shock, etc.





Grasp plug and disconnect Charger from outlet before cleaning.

May cause electric shock, etc.



Power Source

Always grasp plug (not cord) to disconnect Charger from outlet.



Pulling the plug by cord may damage cord, causing electric shock, fire, etc.

Do not subject Charger (sold separately) to strong shocks or impacts while it is plugged into the outlet.



May cause malfunction or injury.

Prohibited

Handset Use & Electronic Medical Equipment

This section is based on "Guidelines on the Use of Radio Communications Equipment such as Cellular Telephones and Safeguards for Electronic Medical Equipment" (Electromagnetic Compatibility Conference, April 1997) and "Report of Investigation of the Effects of Radio Waves on Medical Equipment, etc." (Association of Radio Industries and Businesses, March 2001).



Persons with implanted pacemaker/defibrillator should keep handset more than 22 cm away.



Radio waves may interfere with implanted pacemakers or defibrillators

If you intend to use electronic medical equipment other than implanted pacemaker/defibrillator outside medical facilities, consult the vendor on



Radio waves may interfere with electronic medical equipment.

radio wave effects.

Observe these rules inside medical facilities to avoid effects of radio waves on electronic medical equipment:



- Do not enter an operating room or an Intensive or Coronary Care Unit while carrying a handset.
- Keep handset off in hospitals; cancel the setting that turns handset power on automatically (alarm, etc.) beforehand.

- Even in lobbies or other places where handset use is permitted, keep handset off near electronic medical equipment.
- · Obey medical facility rules on mobile phone use.

Turn handset off in crowds or trains where persons with implanted pacemaker/defibrillator may be near; cancel the setting that turns handset power on automatically (alarm, etc.) beforehand.



Radio waves may interfere with implanted pacemakers or defibrillators causing such devices to malfunction.

General Notes

General Use

- SoftBank is not liable for any damage resulting from accidental loss/ alteration of any data on handset/Memory Card. Please keep separate records of Phonebook entries. etc.
- Handset transmissions may be disrupted inside buildings, tunnels, or underground, or when moving into/out of such places.
- · Use handset without disturbing others.
- Handsets are radios as stipulated by the Radio Law. Under the Radio Law, handsets must be submitted for inspection upon request.
- Handset use near landlines, TVs or radios may cause interference.

· Beware of eavesdropping.

Because this service is completely digital, the possibility of signal interception is greatly reduced. However, some transmissions may be overheard.

- Eavesdropping

Deliberate/accidental interception of communications constitutes eavesdropping.

Inside Vehicles

- · Never use handset while driving.
- · Do not park illegally to use handset.
- · Handset use may affect a vehicle's electronic equipment.

Aboard Aircraft

- Because handset radio waves may impair aircraftoperations, please power off handset while aboard.
 - When handset use aboard aircraft is allowed, please follow instructions of airline personnel.

Function Usage Limits

- The following functions are disabled after handset upgrade/replacement or service cancellation:
 - Camera
 - Media Player
 - S! Appli
 - TV
- After a long period of disuse, these functions may be unusable; establish a Network connection to restore usability.

Handset Care

- If handset is left with no battery or an exhausted one, data may be altered/ lost. SoftBank Mobile is not liable for any resulting damage.
- Use handset between 5°C 35°C. Avoid extreme temperatures/direct sunlight.
- Exposing the lens to direct sunlight may damage the color filter and affect image color.
- · Do not drop or subject handset to shocks.
- · Clean handset with a dry, soft cloth. Using alcohol, thinner, etc. may damage it.
- · Never disassemble or modify handset.
- · Avoid scratching Display.
- · When using headphones, moderate the volume to avoid sound bleed.
- Heavy objects or excessive pressure should be avoided. This may cause malfunction or injury.
 - Do not sit down with handset in a back pocket.
 - Do not place heavy objects on handset in a bag.

- Insert only specified devices into Headphone Port. Malfunction or damage may result.
- Always turn power off before removing battery. If battery is removed while saving data or sending mail, data may be lost, changed or destroyed.

Phenomena of the Keypad Surface Swelling up

- The keypad surface might swell up due to drastic atmospheric changes (alpine regions, aboard in-flight aircraft, etc.) when the Battery Cover is in place.
 This is not an anomaly. It will return to normal after a while.
- If air has entered into the handset, open Port Cover to release the air.
- Slowly close the Battery Cover when closing it so that outside air does not enter in.
- Make sure to not damage the protruding points when firmly pressing on the swollen up parts on the keypad surface. They will return to normal after a while.

Water Resistance

840SC Water Resistance

840SC complies with IPX5 (former JIS protection level 5)^{*1} and IPX7 (JIS protection level 7)^{*2} water protection standards, with Port Covers closed and Battery Cover locked firmly.

- *1 IPX5 compliant means that this handset continues to function as a phone after being subjected to a water jet (approximately 12.5 liters/min.) discharged from a nozzle (inner diameter: 6.3 mm), from all directions (approximately 3 m from handset) for at least 3 minutes.
- *2 IPX7 compliant means that this handset continues to function as a phone and no water seeps inside after being gently lowered into a tank filled with still tap water (at room temperature) to the depth of 1 m, and immersed at the bottom for approximately 30 minutes.
- Malfunction resulting from misuse is not covered by the warranty.

Notes on Usage

- Lock Battery Cover and close Port Covers firmly. If even a mere tiny foreign
 particle (one strand of hair, one grain of sand, minute fibers, etc.) gets into
 the contact surfaces, this will produce the effect of water exposure.
- If Battery/Port Covers are left open liquid exposure may cause handset malfunction/electric shock. Power handset off, then remove battery.
- Since moisture might seep into the crevices between the keypad and hinges when the handset gets wet, remove any water and wipe off the handset with a clean dry cloth. Do not allow it to remain wet.
- In order to prevent water from getting inside when the handset is exposed
 to water droplets in the rain, or when one's hands or the handset get wet,
 absolutely do not open the Battery Cover or Port Cover. Slowly open the
 Battery Cover or Port Cover after the handset has completely dried out. In
 the event that liquid does get inside, do not use the phone, switch it off,
 remove the battery pack, then take it to a SoftBank Shop.
- In order to prevent water from getting inside when the areas around the Port Cover and the Battery Cover are wet, slowly open and close the Battery Cover after the handset has completely dried out.
- Handset is resistant to fresh/tap water at normal temperature (5°C 35°C) only.

Precautions

- Do not expose the handset to or apply to it any liquids (soaps, detergents, soapy water, seawater, swimming pool water, hot spring water, boiling water, chemicals, and perspiration, etc.) other than fresh water or tap water. In addition, do not allow the handset to come into contact with sand or mud.
- If it was exposed to any liquids other than fresh water or tap water, immediately rinse off the handset with water. Position the handset approximately 10 cm. away from a tap or shower head where it can be washed off with a slightly weak low pressure water flow (less than 6 liters per minute, ambient temperature tap water (5°C 35°C)). Wash the handset off by hand, do not use brushes or sponges, and do so with the Battery Cover in place and locked, while keeping Port Cover pressed in.

- Do not expose the handset to bathtubs or swimming pools. In addition, do not use (includes opening and closing the handset and keypad operations) it while in the water.
- Handset was not designed to be water pressure resistant. Do not expose it to strongly flowing (exceeding 6 liters per minute) tap water or shower water, and do not drop it onto water surfaces, or submerge it in water.
- Do not expose handset to extreme humidity for long periods; avoid prolonged use in bath/shower rooms.
- Use handset within 5°C 35°C (up to 40°C for temporary use in bath/shower rooms, etc.) and 35% - 90% humidity.
- Handset is not heat-resistant. Do not use in saunas. Avoid hot air from dryers, etc.
- Avoid extreme temperatures (e.g., near stoves, inside refrigerators, etc.).
- Volume may be low when Microphone/Earpiece/Speaker is wet; dry handset before use. After drying out, the volume will return to normal.
- Avoid placing handset directly on sand. Sand may penetrate Earpiece,
 Speaker, etc., resulting in low volume.
- Do not move handset directly from a cold place to a warm humid place; condensation may occur. Should this happen, dry handset naturally at room temperature.
- · 840SC does not float on water.
- · Keep handset out of heavy rain.
- Do not let liquid-exposed handset remain wet; exposure to cold may freeze liquid causing malfunction.

Maintaining Waterproof Performance

- Do not subject handset to strong shocks or impacts; do not poke Microphone, Earpiece, Speaker, etc. with a cotton swab or sharp object;
- Port Cover and gasket play the important role of maintaining waterproofness.
 Do not remove or damage them. In addition, do not allow foreign particles to adhere to them.

- Do not insert sharp objects through Port Cover gaps; may damage gasket and affect water resistance.
- Do not leave Port Cover bent back for prolonged periods of time to plug in earphonemicrophone or Charger. It might deform the Port Cover and waterproofness might not be maintained.
- If Port Cover gasket is damaged or deformed, replace it with a new one.
- To maintain water resistance, replace gaskets every two years regardless of their condition. For gasket replacements, contact a SoftBank Shop.
- Damaged Battery/ Port Cover affects water resistance; contact a SoftBank Shop.

Charging Precautions

- Battery and optional accessories are not waterproofed. Avoid exposure to liquids or high humidity (e.g., precipitation, bath/shower room, restroom, etc.); may cause fire, electric shock or damage.
- Never charge battery while handset is wet; may cause fire or damage due to electric shock or short-circuit.
- · Close Port Cover firmly after charging via External Device Port.
- Do not touch Charger with wet hands. Electric shock may occur.
- Do not use Charger in rooms in which water is regularly in use (kitchen, bath/shower room, etc.); may cause fire or electric shock.

If handset get soaked, see " 水抜きのしかた "(�P.15-6).

If Port Cover get detached, see "端子キャップの取り付けかた"(�P.15-7).

Precautions Regarding the UV Checker

- In order to be able to take correct measurements when using the UV Checker, aim the UV Sensor two or three times at the sun.
- The UV Checker may not be able to take correct measurements since it might be influenced by the weather and surrounding buildings.
- Use the UV Checker as a reference since it might not be able to take correct measurements.
- Correct measurements might not be taken if the UV Sensor is soiled (fingerprints, foreign particles, etc.).
- Be aware that the UV Sensor might be damaged by drastic temperature fluctuations.
- The UV Sensor may not function if the handset is dropped, or suffers a strong impact.
- Do not allow the UV Sensor to remain exposed (opened handset) to strong sunlight and ultraviolet rays. Be aware that this might damage the sensor.
- The UV Checker does not function when the handset is closed. Use it with the handset opened.
- · If the UV Checker is successively used, it may not function normally.
- The area surrounding the UV Sensor might become discolored due to prolonged usage. This is not a malfunction.
- . The UV Sensor cannot function in water.
- The actual intensity of the ultraviolet light might vary with the measurements
 of the UV Checker. Always use sunblock lotion etc. to protect one's skin from
 ultraviolet rays.
- Even though the UV Checker shows, "Not strong (you can safely spend time outside)," this does not mean that one is safe.
- The UV Checker's measurement times may vary depending upon the surrounding environment and conditions.

Copyrights

Copyright laws protect sounds, images, computer programs, databases, other materials for copyright holders. Duplicated material is limited to private use only.

Use of materials beyond this limit or without permission of copyright holders may constitute copyright infringement, and be subject to criminal punishment. Comply with copyright laws when using images captured with handset camera.

The software contained in 840SC is copyrighted material; copyright, moral right, and other related rights are protected by copyright laws. Do not copy, modify, alter, disassemble, decompile, or reverse-engineer the software, and do not separate it from hardware in whole or part.

SAR Certification

840SC meets the technical standards of Ministry of Internal Affairs and Communications (MIC) regarding radio wave absorption by a human body.

These technical standards are established on a scientific basis to prevent radio waves emitted from wireless devices such as mobile phones that are used close to human head from affecting human health. These standards assure that the SAR (Specific Absorption Rate), an indicator of the amount of average energy absorbed in the side of a human head, must not exceed the permissive value of 2W/kg*. This value includes a substantial safety margin designated to assure the safety of all persons, regardless of age and physical size. The value is equal to the international guideline recommended by International Commission on Non-Ionizing Radiation Protection (ICNIRP) that has a cooperative relationship with the World Health Organization (WHO). The highest SAR value for 840SC is 0.183 W/kg. This value is obtained in accordance with the MIC testing procedure with the mobile phone transmitting at its highest permitted power level. While there may be differences in the SAR levels depending on phones, they all meet the MIC's permissible value. Because mobile phones are designed to employ the minimum power level required for the communication with the base station, the SAR of the phone during a call is usually below the maximum value. For further information about SAR, please see the following websites: MIC: http://www.tele.soumu.go.ip/i/ele/index.htm ARIB: http://www.arib-emf.org/

 The guideline is defined by relevant laws and regulations associated with the Radio Law (No. 2 of Article 14 of Ordinance Regulating Radio Equipment).

SoftBank's Body SAR Policy

- Body SAR: The SAR value at the maximum transmission power when continuously talking with handset placed on the body and using earphonemicrophone.
- ** Specific Absorption Rate (SAR): The value measured when having talked continuously for 6 minutes.
- *** Placement on the body: Measurements are taken with the rear of handset facing the body at a distance of 1.5 cm as the ordinary handset position. In order to comply with radio frequency exposure requirements, use an accessory (e.g. belt clip, holster) that does not contain metallic parts to maintain a 1.5 cm separation between the body and handset. For further information, see the following SoftBank website: http://www.softbankmobile.co.jp/ja/info/public/emf/emf02.html

European RF Exposure Information

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested at the ear was 0.737 W/kg*. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide. In this case, the highest tested SAR value is 0.183 W/kg.

As SAR is measured utilizing the devices highest transmitting power the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network. The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a hands-free device to keep the mobile phone away from the head and body.

 The tests are carried out in accordance with international guidelines for testing.

						······································	
•••••	• • • • • • • • • • • • • • • • • • • •	••••••	••••••	•••••	• • • • • • • • • • • • • • • • • • • •	•••••••••••••••••••••••••••••••••••••••	
•••••							
•••••							
•••••							

.